

085

Make: Ford
Model: AU Falcon
Subject: Service light reset

As with EF & EL Falcons, the AU Falcon has a small light in the shape of a spanner that illuminates in the lower left hand corner of the dash panel when the vehicle is due for its next service. The procedure to remove the service light and reset it for the next service interval is simple and Injectronics recommend to follow this procedure.

1. Turn ignition on (don't start engine)
2. Hold down reset shaft for between 11 and 13 seconds
3. An audible beep will be heard after the shaft has been released to indicate that the command has been received and the light should go out.

Note: If the button is held down too long or not long enough, the spanner light will not clear.