

Injectronics

TECHNICAL BULLETIN

JEEP – CHEROKEE 4.0L

#T0103

Make: Jeep

Model: Cherokee 4.0L

Subject: Engine will not start

TEST: Check for ignition & injection pulses while cranking the engine. Check for 5 volt supply voltage to the various sensors e.g. CRANK, CAM, MAP & TPS. If no 5 volt supply voltage is evident, disconnect the crankshaft position sensor located on the bell housing & check if the 5 volt supply is evident at the various sensors.

CAUSE: The crankshaft position sensor pulls the 5 volt supply voltage low.

Replace the crankshaft position sensor.